


97-02-002 Component Location, Component Location Views , LH engine compartment



Engine Control 2,0 I EFI Turbo, RS Cosworth (29)

Diagnostic and Earth Connections - EEC-IV

Pins 17 and 48 lead to the self test connector (D19).

Pins 18 and 19 lead to the data link connector (DLC) (D20).

For vehicles before MY 95, pin 29 leads to the service connector (D22).

Pins 16, 40, and 60 are connected to earth G1004 and pin 20 is connected to earth G1096.